Quick Installation Guide

Step 1

Package contents

Open the box and make sure all items listed below are included:

- Integrated wireless IP camera 1 pc
- Wireless antenna 1 pc
- AC power adaptor 1 pc
- Quick installation guide 1 pc
- CD-ROM 1 pc
  (IPC monitor client and search application)
- Network cable 1 pc
- Mounting bracket and hardware 1 set

Step 2

Product overview

XPY 530

Step 2

1. Night vision LEDs
2. Lens
3. Light sensor
4. Built-in microphone
5. Network status LED
6. Operation status LED
7. SD card slot
8. 5V DC in
9. Wireless antenna
10. Reset button
11. Network port (RJ45)
12. Audio input
13. Audio output
14. Alarm input and output ports

Step 3

Basic set up

Connection of the IP Camera to the network

1. Begin by attaching the mounting bracket and the antenna to the device.
2. Select a mounting position on a wall or ceiling.
3. Use the screws and wall plugs supplied to fix the mounting base.
4. Insert the Ethernet cable to the RJ45 interface of the IP camera.
5. Connect the other end of the network cable to your Ethernet switch, hub or router.
6. Plug the camera to the wall outlet using the supplied AC adaptor to turn it on.

Step 3

Warning: Make sure to use the supplied power adapter for making the connections to the AC mains. The use of a different adaptor may cause damage to the camera, heat up or catch fire.
Any damage caused to the camera by using the incorrect power adaptor will void the warranty. Verify that the mains voltage (110V or 220V) and frequency (50 or 60 Hz) of your location match those specified on the label.

Step 4

Getting started

4.1 System login

1. To access the camera using the web interface, open the web browser in your computer and type the device IP address: **192.168.0.126** and hit enter.

2. The IP address of the camera must fall within the same range specified by your router.
   Note: Nexxt Solutions routers are configured within such parameters. When using routers from other manufacturers, you may be required to configure the IP address of the camera manually, so that the value assigned falls within the existing range of your network. For details, please refer to the user manual.

Step 4

3. In this step, the **Log in** window will appear on the screen. By default, the administrator's username and the password is **admin**. When done, click **OK** to continue.

Step 4

4. The camera main interface provides two different access modes, in addition to access to controls and the configuration parameters of the camera, which are based on the privileges assigned to each particular user. (Please refer to the manual for details regarding the multi-level management system).
5. For the purposes of this quick installation guide, we are going to describe the video view using the IE browser. Please note that the user will be required to download ActiveX controls when using this interface for the first time.

Step 4

Main User Interface (as seen in Internet Explorer)

Step 4

6. After clicking on **Download**, select **Run** to allow the ActiveX controls to be automatically installed in your computer.

File download dialog box

Step 4

4.2 Camera web interface

As soon as you log in, the main monitoring page will be displayed, as shown below:

Web browser interface

Step 4

1. **Status bar description:**
   a) Connection status indicator
   b) Recording status indicator
   c) Zoom control buttons
   d) **Directory configuration button:** sets the path for saving recorded files
   e) **Microphone button:** when enabled, the operator can remotely speak to the people near the camera
   f) **Speaker button:** when enabled, the operator can listen to the people standing near the camera
2. a) **Video stream selection:** Choose the first, second or third stream depending on the bandwidth required by the type of connection you are using
   b) **Views:** Full screen, Quad view and Multi-split screen

Step 4

3. Direction control arrows
   Center position button
   Preset position set and call buttonsHorizontal and vertical patrol
4. Snapshot button
   Video recording button
   SD card storage
   Playback button
5. IP camera settings interface
6. Home Page

Step 4

- When logging in as an **Administrator,** the user will have full access to all the controls, menus and settings available in the device.
- As an **Operator**, the user will have access to the main monitoring page, and to a limited number of parameters associated with the operation of the camera.
- As a **Visitor**, the user is only allowed to view the main monitoring page for all the enabled cameras, having no access to any of the controls or configuration settings on the device.

For detailed information about different configuration options, advanced operation, and the free monitoring software, please refer to the user manual included in the CD ROM.